

LINSN HUB40A LED DATA TRANSMIT CARD,HUB40 LED HUB CARD WORK WITH RV901,RV801
[LED RECEIVING CARD](#)

Function:Allocate the right signals of receiving card to [led display module](#).

Specification:

- Socketed in RV801 and rv901 [led receiver](#).
- HUB Model is chosen according to the pin-out of LED Module.
- To allocate the right signals to LED Module pins.
- Use flat cable (IDE).
- If the HUB pin-outs is not exactly the same as the [outdoor led module](#) pin-ins,jumper wire can be applied.
- Note:

N= GND,

L= LAT or ST,

S= CLK,

O= OE,

E=/OE

R=red data,

G=green data,

U=blue data,

A,B,C,D= row signal,

H=after decoding row signal

F=NC,

V=VCC.

